



THERMOSKIN SPRAY UNIT

5 Spray Heads:

- One on top
- Two each side (middle ones are adjustable with Phillipshead screwdriver)

Pump



Power Switch

Dip Tube

Sensor and Primer Switch

STORE THERMOSKIN PRODUCT at ROOM TEMPERATURE
Keep the Product at room temperature or above 6°C.

INSTRUCTIONS FOR USE:

1. Unscrew cap of ThermoSkin Product
2. Take dip tube out of cover
3. Insert dip tube into ThermoSkin Product
4. Screw cap down when dip tube is inserted
5. Connect the electrical lead to the machine and turn on power.
6. Turn on the prime switch to prime the unit.
7. If it does not prime there is an air lock in system: open the spray jet on top to remove the air, then replace jet. (no tools required to open the jets)
8. CLEAN THE UNIT when the unit is no longer required for the day: Remove the dip tube from the ThermoSkin Product and insert it into a drum of Methylated Spirits. Activate the unit by using the prime switch. Allow any residual product to be flushed through (approx 30 seconds)
9. Once this cleaning procedure is complete, put the dip tube back in its holder to seal from dirt and dust.
10. Switch off power.



HENRY KING

TEL: 02 9534 7422 | MOB: 0418 641 645

EMAIL: henry@thermoskin.com.au | WEB: www.thermoskin.com.au